


Nano Soldering Station

纳米焊台 Instruction Manual 使用说明书



聲明:本公司保留改進升級產品的權利,產品規格及設計如有變更,認不另行告知。 Statement: The company reserves the right to improve and increase.

Statement: The company reserves the right to improve and upgrade products, product specifications and design are subject to change without notice.

接地线 Earth cable

产品清单/Product list



MA-SD01 Nano Soldering Station






SIMECHADIC.














- Welding nozzle hot plug replacement frame
- 2 2 inch screen control system
- 3 Switch / Adjustment

T210 handle + soldering penci

T245 handle + soldering pencil T245手柄+焊笔

> T115 handle + soldering penci T115手柄+焊笔

Note: you can choose A. B. C freely 备注:A、B、C可自由选择 T210手柄+焊笔

- 4 System Settings
- 5 Switch / Adjustment
- 6 Welding nozzle cleaning sponge
- Welding nozzle cleaner
- 8 Cable support rod
- 10 Handle access 9 Handle rack at dormancy
- The USB interface
- **B** Power input 2 Earth wire interface
- 15 The power switch 14 Fuse box

产品简介/Product introduction

- 焊嘴热拔插更换架
- 2 2英寸屏幕控制系统
- ② 巧英/遍點
- △ 系统设置
- 5 切换/调整
- ◎ 焊嘴清洗海绵
- 3 线缆支撑杆 □ 焊嘴清洁器
- 手柄休眠放置架 手柄接入口

6

- → USB接口
- 接地线接口

5. Temp Unit

8. Language Set

3. Dormanoy Delay

O 6. Sound

System MENU

System MENU

. Temp Group

工作界面/Working interface

焊笔简介/Introduction of soldering Pencil











350°C 350°C

200°c

System MENU

Sleep in

Cross tate south and a south a south and a south a south





手柄简介/Introduction of the handle







人体工程学设计, 握感舒适、耐摔、不易老化、隔热、防滑。 采用优质铁氟龙硅胶线、质地软、耐高温, 不易破损, 使用安全。 Ergonomic design, comfortable grip, drop resistance, not easy to aging, heat insulation, and non-slip. Use high-quality Teflon silicone wire, soft and high temperature resistance, not easy to break, and safe to use.

9

操作方法/Operation method

1.工作中/Working

2.休眠/Dormancy



当焊笔离开支架时,笔尖温度会迅速恢复到工作 温度

When the soldering pencil leaves the holder, the emperature of the tip will return to the working emperature quickly



MASTER WORKER

单击唤醒,继续点击即可减小温度

Click to wake up, continue to clic to decrease the temperature

click to increase the temperature

单击唤醒,继续点 击即可增加温度 Click to wake up, continue to



当焊笔插入支架时,笔尖会迅速降温到休眠状态

When the soldering pencil is inserted into the holder, the tip will cool down to a dormant state quickly

200°C 焊笔休眠中

休題

200°C

Sleep Temp

休眠状态下可调整温度参数 Can adjust temperature parameters in dormancy

丝盒拆装/Disassembly of fuse box

Step 1: Confirm the location of the fuse box -步:确认保险丝盒位置



第二步:撬开保险丝盒 Step 2: Pry the fuse box



如右图所示 第三步:取出保险丝盒

as shown of the picture Step 3: Take out the fuse box,



焊笔安装 [Installation of soldering pencil]



第一步:将手柄轻插焊笔吸 住即可,拿起手柄

Step 1: Insert the handle into the soldering pencil lightly and hold it, then pick up the

Step 2. Fix the soldering pencil on the placement

frame, as shown in the figure below

nandle



架上,如下图所示 第二步.将焊笔固定在放置



第三步.将手柄向下用力卡 住焊笔,离开即可开始工作

down and clamp the soldering pencil firmly, leave it to start working Step 3. Push the handle

焊笔拆装/Disassembly of soldering pencil (Disassembly of soldering pencil)

焊笔拆卸

换架中


Step 1: Working 第一步:工作中




第二步.将手柄插入焊笔更




第三步.拔出手柄即可完成





警告/Warning



Except for soldering or rework, do not use it for other purposes. Improper use may cause damage to the soldering station;

● 电源线插入对应的接口。使用前确保已正确接地。请勿在带电部件上工作, 不用时应将工具放在支架上以激活睡眠模式;

Plug the power cord into the corresponding interface. Ensure that it is properly connect the earth wire before use. Do not work on live parts. When not in use, place the tool on the stand to activate the dormancy mode;

● 开机时需有人看管设备,不要阻塞通风系统。热量会引起易燃产品着火, 避免助焊剂与皮肤或眼睛接触,操作小心焊接时产生的烟雾,以免刺激 到眼睛;

There should be someone to nearby when turning on the machine, and do not block the ventilation system. Heat can cause flammable products on fire. Avoid contact between the flux paste and the skin or eyes. Be careful with the fumes generated during soldering to avoid irritating the eyes;

●保持工作场所整洁。佩戴适当的防护眼镜和手套时,避免人身伤害务必小心处理液态锡废料,避免引起灼伤;

Keep the workplace clean and tidy. Wear appropriate protective glasses and gloves to avoid personal injury. Be sure to handle liquid tin waste carefully to avoid burns;

● 此设备禁止儿童单独玩耍和使用;

Prohibit children from playing and using alone;

) 使用此设备前需详细了解产品使用说明; Before using this equipment, you need to understand the product instructions in detail;

保修条款/Warranty card

商品自售出之日起7七日内,如发生性能故障,商品本身及外包装必须保持完整、无划伤,可更换同种型号的商品。

Within 7 days from the date of sale of the product, if there is a performance failure, the product itself and the outer packaging must be intact and free of scratches, then you could replace the same model one.

2.商品自售出之日起保修一年,终生维护。配件不在保修范围内。 The product is guaranteed for one year from the date of sale, and it is maintained for life. Accessories are not covered by the warranty.

3.保修服务只限正常使用下有效。

The warranty service is only valid under normal use

4.一切人为损坏、自行拆机、使用不当造成的损坏,不在保修范围内。保修是需提供本卡,未能提供本卡或私自涂改本卡,本公司有权做非保修处理。

All damage caused by man-made damage, self-dismantling, or improper use is not covered by the warranty. This card is required for warranty. If this card is not provided or the card is altered privately, we preserve the right of not providing warranty service.

(Warranty record)	全	用户姓名 (User name)
		购买日期 (Date of purchase)
	*	产品型号 (Model No.)