


toocki



TWS Wireless Earphone **User Manual**

Please read this user manual carefully before use and keep it properly.

1. Product Parameters

Brand: Toocki

Name: TWS Wireless Earphone

Model No.: HE-080

Material: ABS

Earphone Capacity: 30mAh

Charging Case Capacity: 320mAh

Rated Voltage: 3.7V

Charging Time: About 1 hour

Charging Port: USB-C

Input: 5V = 1A

BT Version: V5.3


Waterproof Rating: IPX4

Earphones Weight: 6.7g

Earphones+Charging Case Weight: 43.1g

*The above data are measured by the toocki laboratory, the actual use will be slightly different depending on the specific circumstances.


2. Product Diagram




Charging Case



Indicator Light



USB-C Input



3. Package List

TWS Earphones	*2
Charging Case	*1
USB-C Charging Cable	*1
User Manual	*1

4. Earphone User Manual

Power On



Remove the earphones from the charging case and it will turn on automatically.

Power Off



Put the earphone back into the charging case and close the cover to turn off the earphone and charging.

0000 ▶ Bluetooth Pairing

1. Open the charging case, the left and right earphones will be automatically connected, there will be a "paring" sound after connection. At this time the earphone into pairing mode, red and blue light indicator alternately flashing;
2. Search for the model name on the phone (HE-080) and connect, there will be a "connected" sound after successful connection, which means the pairing is successfully.

0000 ▶ Charging

When the earphone is about to run out of power, you need to charge the earphone in time.

Earphones charging: Put the earphone into the charging case, it will automatically start charging.

Charging case charging: Use USB-C charging cable to connect to the charger.

5. LED Indication Status

0000 ▶ Earphone

LED color: Red, blue


- Earphone pairing: Main earphone is flashing with red and blue lights
- Earphones are connected to the phone: LED lights off
- Earphones into the charging case: Red light on 10s, then light off

0000 ▶ Charging case

LED color: Green, orange

- Charging case charging earphone: Green light always on
- Charging case charging: Orange light flashing
- Fully charged: Orange light always on
- Charging case in low battery: Green light flashing

6. Touch Area User Manual



Pause/Play Music

Tap either side of touch area 1 time



Volume Adjustment

+: Tap the R-side touch area 2 times

-: Tap the L-side touch area 2 times



Previous track

Tap the L-side touch area 3 times



Next track

Tap the R-side touch area 3 times



Answer the call

Tap either side of touch area 1 time



Hang up

Tap either side of touch area 2 times



Reject the call

Long press either side of touch area 1 seconds

7. Using Environment

Working temperature: -10°C ~ +45°C

Storage temperature: -20°C ~ +70°C

8. Reminder

1. To protect your hearing, please keep the volume at a normal level. Avoid listening to high-volume music, as it may damage your hearing.
2. In extreme outdoor weather conditions, such as thunderstorms, please refrain from answering calls or using earphones.
3. There may be occasional audio and video synchronization issues.
4. If you don't use the device frequently, please make sure to charge it at least once a month to ensure better battery life.
5. If your earphones remain connected to your device or if they are not charging when placed back in the charging case, please clean the connectors.
6. Please ensure that the voltage of the charger you use for charging does not exceed 5V = 1A to avoid damaging the product due to over voltage.

9. Tips

1. Keep the product dry and avoid placing it in a damp environment to prevent any impact on the internal circuits of the product.
2. Do not expose the product to direct sunlight or high temperatures. High temperatures can shorten the lifespan of electronic components, damage the battery, and cause deformations in certain plastic parts.
3. Avoid placing the product in extremely cold areas to prevent any damage to the internal circuit board.
4. Do not attempt to dismantle the product. The product may be damaged if not taken apart by a professional.
5. Avoid dropping, subjecting to strong vibrations, or hitting the product with hard objects to prevent any damage to the internal circuits.
6. Do not use strong chemicals or cleaning agents to clean the earphones.
7. Avoid using sharp objects to scratch the surface of the product, as this may damage the casing and affect its appearance.

10. Warranty (1-year period)

The manufacturer's warranty is void under the following conditions, including but not limited to:

1. Improper storage or modification.
2. Accidents, misuse, abuse, contamination and other external factors.
3. Use of unspecified adapters or accessories.
4. Loss or damage during transportation.
5. Damage caused by failure to follow instructions.

*Consumables are not covered under warranty.

11. Customer Service

We have an award-winning warranty, exchange and customer service team that will respond within 48 hours to any issues you may have.

The main store is closed on Saturdays, Sundays, and holidays, and emails received after 5pm on weekdays or holidays will be answered the next business day.

*If the product is defective or returned, please contact us with your order number within the warranty period. Please do not discard product parts as they may be needed for inspection/repair.

Warning



Please follow the safety instructions to avoid risks of fire, electric shock, damage, or other injuries.



This equipment complies with the provisions of Directive 2012/19/EU. It is strictly forbidden to dispose of this equipment with general waste and must be recycled. This symbol indicates that this product cannot be used as regular domestic waste for disposal, and must be delivered to the corresponding waste recycling station that is capable of recycling electrical and electronic equipment.




WARNING: EN: KEEP THE PRODUCT CLEAN AND DRY DURING USE
 IT: MANTENERE PULITO E ASCIUTTO IL PRODOTTO QUANDO LO SI UTILIZZA

DE: BEI DER VERWENDUNG DES PRODUKTS SAUBER UND TROCKEN HALTEN

FR: MAINTENIR PROPRE ET SEC LORS DE L'UTILISATION DU PRODUIT

ES: MANTÉNGASE LIMPIO Y SECO CUANDO UTILICE EL PRODUCTO



EU

REP

Name: E-CrossStu GmbH
 Address: Mainzer
 Landstr.69, Frankfurt am
 Main, Hessen, 60329
 Email: e-crossstu@outlook.com

UK

REP

Company: YH Consulting Limited
 Address: C/O YH Consulting Limited
 Office 147, Centurion House,
 London Road, Staines-upon
 -Thames, Surrey, TW18 4AX

FCC ID: 2A2BYHE-044



Manufacturer: Shenzhen Toocki Network Technology Co., Ltd.

Add: Room 308, Building A1, Xuexiang Industrial Park, Yuanchuang Space, No. 33, Zhonghao 2nd Road, Xiangjiaotang Community, Bantian Street, Longgang District, Shenzhen

Hotline: +86 0755-89399212

Website: www.toocki.com

Email: official@toocki.com

TCYMX-0106 / Made in China