

9827 /9827K Product Instruction

Welcome to use 9827/9827K LED Magnifying Lamp. Please read the manual carefully before use, it will help you to experience the various functions of the product much better.

I. Parts list

1. LED Magnifying Lamp 1 pc
2. Table clamp 1 pc
3. Adapter 1 pc
4. User's manual 1 pc

II. Product Parameter

Lamp working voltage: DC12V

Light: 81pcs LED

Adapter working voltage: AC100-250V

Frequency: 50-60Hz

Power: 8W

Lens: Glass

Diopter: 3D/5D/8D

Luminance: 1000Lm

Lux: 3800Lux

Colour Temperature: 6000K

Plywood thickness required: ≤ 70 MM

LED light Switch: single point touch capacitive switch, with dimmer

III. Product Instruction

1. You will see the overall foam packing after opening the box, and please check all the parts if fully equipped.
2. Please fix the table clamp on the suitable position ,where the plywood thickness requires ≤ 70 MM, then insert the lamp arm into the hole of the table clamp, rotating the lamp body to the best position, connect the adapter and put it in socket.
3. There is a single point touch capacitive switch on the back of head part, use finger to click the light symbol on the lamp, the light is on, again click, light is off. The switch also includes dimmer, keep pressing the switch to change the brightness of the light.
4. There is a screw on the top of arm, can find it when fold the arm completely, it is used for adjusting the spring power of the arm when necessary. When tighten the screw in clockwise, the spring power gets stronger, when loosen the screw in anticlockwise, the spring power gets weaker.