

9981 Product Instruction

Welcome to use 9981 LED Magnifying Lamp. Please read the manual carefully before use, it will help you to experience the various functions of the product much better.

I. Parts list

1. LED Magnifying Lamp 1 pc
2. Table clamp 1 pc
3. Adapter 1 pc
4. User's manual 1 pc

II. Product Parameter

Lamp working voltage: DC12V

Light: 81LED, 1Superbright LED, 1UV

Adapter working voltage: AC100-250V

Frequency: 50-60HZ

Power: 11W

Lens: Glass

Diopter: 3D, 15D/ 5D,20D

Luminance: 1000Lm

Lux: 4000Lux

Colour Temperature: 6000K

Source life: 25000h

Plywood thickness required: $\leq 70\text{MM}$

Main LED light Switch: single point touch capacitive switch, with PWM dimmer

Superbright LED light Switch: single point touch capacitive switch

UV LED light Switch: single point touch capacitive switch



PC Cover



Touch Switch



138mm/60mm Lens



Clamp

III. Product Instruction

1. You will see the overall foam packing after opening the beautiful gift box, and please check all the parts if fully equipped.
2. Please fix the table clamp on the suitable position, where the plywood thickness requires $\leq 70\text{MM}$, then insert the lamp arm into the hole of the table clamp, rotating the lamp body to the best position, connect the adapter and put it in socket.
3. There are 3 touchable switches on the front of head part, the left one for superbright LED, the middle one for main LED light, and the right one for UV LED.
4. These 3 switches are single point touch capacitive switch. For the left one and right one switch, use finger to click to the light symbol on the lamp, then the light is on, again clicking, the light is off, so the cycle to repeat. For the middle switch, it includes PWM dimmer, clicking the light symbol less than 550ms, which can control the light on and off. Touching it more than 550ms, this can control the PWM dimmer. Keep on touching, the brightness will be increased or decreased gradually. The brightness will stop changing when released. If touching more than 3S, the brightness will be up to the brightest or the darkest and no changing, so the cycle to repeat.

IV. One-year warranty

Guarantee the product and its accessories will be no damaged within the first year from the date to the original purchaser.

But this warranty does not cover:

1. Any abrasion under normal use
2. Any defect caused by wrong usage and by external force.
3. The damage caused by force majeure.

The company has the final right.

If any question, please contact with the local dealer.